

## **Yaesu FT-991**

Press "Menu/Setup" button.

Rotate Multi Knob to Menu #055 - CW AUTO MODE

Press "Select"

Rotate Multi Knob to "ON"

Press "Enter"

Rotate "Multi Knob" to Menu #059 - CW FREQ DISPLAY

Press "Select"

Rotate Multi Knob to "PITCH OFFSE"

Press "Enter"

Press "Menu/Setup" button to exit menu back to waterfall display.

Set desired frequency on VFO A to whatever band you like for SSB.

Press your paddle or key and watch display and read either 700hz up or 700hz down from your entered SSB frequency depending on what band you are on.

The FT-991A will automatically go up for USB and down for LSB on each band.

Hope this helps!

73

Stray W8SCS